



Sentry® Spotting Scope Instructions

Congratulations on the purchase of your Bushnell® **Sentry®** Spotting Scope, a versatile high-performance spotting scope offering a wide range of terrestrial viewing. The **Sentry®** Spotting Scope features fully coated prisms and lenses for increased light transmission and image brightness, variable power eyepieces, non-reflective armoring and built-in peep sight (straight-thru models only) for ultra fast precision viewing. Complete with non-reflective tripod. All Bushnell® **Sentry®** models come with a convenient hard storage case (except for the 45-degree model).

MOUNTING

Remove the spotting scope and tripod from the hard storage carrying case. Screw the tripod attachment screw into the tripod mount hole located on the base of the spotting scope. Spread the tripod legs and set on a solid surface.

FOCUSING

The spotting scope is focused with the focus ring. For models with a 50mm objective, the eyepiece will move “in” and “out”, depending on the direction the ring is turned. When the tube is all the way “out”, the spotting scope is at the closest focus position.

MAGNIFICATION

To change magnification, grasp and rotate the knurled portion of the eyepiece. It may be necessary to re-focus when the magnification is changed.

USING THE TRIPOD

To pan side to side or up and down, unloosen the tripod control handle by rotating it counterclockwise. To lock into a desired position, rotate the tripod control handle clockwise.

SPOTTING SCOPE USE

Remove the dust caps. Point the spotting scope as desired (as described under FOCUSING).

CAUTION: DO NOT LOOK AT THE SUN THROUGH THIS SPOTTING SCOPE AS SEVERE DAMAGE TO YOUR EYES MAY RESULT!

CARE

The lenses of your spotting scope are 100% hard magnesium fluoride coated for highest light transmission. As with any optical coated, special care must be taken in cleaning the lenses. Moisten the surface of the lens slightly and wipe dry using a circular motion starting at the center of the lens. Wipe or brush off any dirt or dust on the outside of the spotting scope and tripod.

CAUTION

Never disassemble your spotting scope or tripod. Special tools and equipment are required for service and irreparable damage can result from untrained attempted service. Unauthorized service may also void the warranty.

LIFETIME LIMITED WARRANTY

Your Bushnell® spotting scope is warranted to be free of defects in materials and workmanship for the lifetime of the original owner. The Lifetime Limited Warranty is an expression of our confidence in the materials and mechanical workmanship of our products and is your assurance of a lifetime of dependable service. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse or improper handling, installation or maintenance of the product.

Any return made under this warranty must be accompanied by the items listed below:

- 1)A check in the amount of \$10.00 to cover the cost of handling
- 2)Name and address for product return
- 3)An explanation of the defect
- 4)Product should be well packed in a sturdy outside shipping carton to prevent damage in transit and return postage prepaid to the address listed below:

IN U.S.A. Send To:
Bushnell Performance Optics
8500 Marshall Drive
Lenexa, Kansas 66214

IN CANADA Send To:
Bushnell Performance Optics
25A East Pearce Street, Unit 1
Richmond Hill, Ontario L4B 2M9

For products purchased outside the United States and Canada please contact your local dealer for applicable warranty information. This warranty gives you specific legal rights. You may have other rights which vary from country to country.

©2001 Bushnell Performance Optics