


BISHICI BACKSTRACK GPS HuntTrack

RECORD YOUR TRACK ➤ FIND YOUR WAY BACK



Open battery cover. Insert 3 AAA batteries (note serial #). Close cover.



Go outdoors. Press & hold POWER button to turn on. Wait for GPS satellite lock (icon stops blinking).





Press POWER briefly to select a Location icon (Tent, Truck, Tree, Treestand, Deer, #1-20). Press & Hold MARK to save current location. 4

To return to the location, select its icon. Display indicates direction and distance back to the location.



6

Press TRIP, then press & hold it to start a new trip. Hold TRIP again to stop the trip. (See next page for DATA function directions)





Go to http://www.hunttrackgps.com and register your HuntTrack. You'll receive download instructions for Adobe[®] Air[®] and the HuntTrack App.





Turn on HuntTrack, connect USB to PC. The HuntTrack App will launch*.



Enter the User Name and Password you used to setup your account, and select "LOGIN"



* Click icon in "Applications" on MAC.





Moon Phase Data

& Weather Trend

Press the TRIP/DATA button briefly to view and cycle through the Hunting Data screens



Animal Activity Meter & Predictive Graph



Previous Route Between Locations

HuntTrack APP FEATURES *



- a. Trip Folder (right click to rename)
- b. Trips taken same day (click Trip folder to open, right click to rename trip)
- c. Route of highlighted trip
- d. Map View types (click to change view).
- e. Zoom slider & position pad
- f. Click "eye" to hide a trip.
- g. Click "handle" to view Trip Graphs.

- h. Click "+" to add new folder. Drag trips into it.
- i. Drag trips into "trash" to delete.
- j. Click "Share" to post on Facebook.
- k. Click "Export..." to save as a .jpg file or send via email.
- I. Click "Settings" to select the menu language and English/metric units.
- m. Click "Logout" when done. Your maps will be automatically saved.

* Appearance of application may change with updates

Full Instruction Manual online at: www.bushnell.com/manuals/gps

ONE YEAR LIMITED WARRANTY

Your Bushnell[®] HuntTrack[™] GPS unit is warranted to be free of defects in materials and workmanship for one year after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than a Bushnell Authorized Service Department.

Any return made under this warranty must be accompanied by the items listed below:

- 1) A check/money order in the amount of \$10.00 to cover the cost of postage and handling
- 2) Name and address for product return
- 3) An explanation of the defect
- 4) Proof of Date Purchased
- 5) Product should be well packed in a sturdy outside shipping carton, to prevent damage in transit, with return postage prepaid to the address listed below:

IN U.S.A. Send To:

Bushnell Outdoor Products Attn.: Repairs 9200 Cody Overland Park, Kansas 66214

IN CANADA Send To:

Bushnell Outdoor Products Attn.: Repairs 25A East Pearce Street, Unit 1 Richmond Hill, Ontario L4B 2M9

For products purchased outside the United States or Canada please contact your local dealer for applicable warranty information.

In Europe you may also contact Bushnell at:

Bushnell Germany GmbH European Service Centre Mathias-Brüggen-Str. 80 D-50827 Köln GERMANY Tel: +49 221 995568-0 Fax: +49 221 995568-20

This warranty gives you specific legal rights. You may have other rights which vary from country to country. ©2012 Bushnell Outdoor Products

Warnings and Notices

GPS System & Location Accuracy Notice:

The Global Positioning System (GPS) is operated by the government of the United States, which is solely responsible for its accuracy and maintenance. The system is subject to changes which could affect the accuracy and performance of all GPS equipment. The inherent nature of the GPS system itself limits the accuracy of the distance indicated on the unit's display to within about ±3~5 meters (or yards) of the actual marked location.

Warning:

This device is intended as a supplemental handheld navigation aide only. The user assumes all responsibility associated with the use of this product. It must not be used for any purpose requiring precise measurement of location, direction, distance, velocity or topography. This device should not be used for any aircraft navigation applications.

Vehicular Use Notice:

Bushnell is committed to the safe and responsible enjoyment of the outdoors.

Do not use this product while driving. An accident can result in property damage, injury or death if the operator fails to practice prudent driving practices. It is the sole responsibility of the driver of any vehicle to operate the motor vehicle in a safe manner. Information from the GPS unit can distract the operator of a motor vehicle. It is unsafe to operate the controls of the GPS unit while operating a motor vehicle. If used in a motor vehicle, it must not be used by the operator of the motor vehicle. If it is used in a motor vehicle it must be mounted in a manner such that it does not distract the operator, does not interfere with the operator's field of view, and does not block or interfere with the air bags or other safety mechanisms of the motor vehicle. Windshields and car windows with integrated metallic materials, such as defrosters, or car window tinting films, can degrade GPS reception inside a car.

Liability Notice:

In no event shall Bushnell be liable for any incidental, special, indirect or consequential damages, whether resulting from the use, misuse, or inability to use this product or from defects in the product.

Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you.

FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \cdot Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

Adobe®,Air®, Copyright © 2011 Adobe Systems Incorporated. All rights reserved.

Windows® Copyright © 2011 Microsoft. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. All rights reserved.

Mac®, Copyright © 2011 Apple Inc. Mac® is a registered trademark of Apple Inc. in the United States and other countries. All rights reserved.

Third-party marks and brands are the property of their respective owners. All products, dates, and figures are preliminary and subject to change without notice.

Google is the registered trademark of Google, Inc.

Please read the Google® Maps Terms of Service at: http://maps.google.com/intl/en/help/terms_maps.html

í CE



Full Instruction Manual available online at: http://www.bushnell.com/manuals/gps

Bushnell Outdoor Products 9200 Cody, Overland Park, Kansas 66214 (800) 423-3537 • www.bushnell.com

©2012 Bushnell Outdoor Products