Quick Start Guide

1. Go to **www.wirelesstrophycam.com** and click "**SETUP A NEW ACCOUNT**".
2. Fill in your personal info and set your notification preferences. Click "**CREATE**".
3. Click the plus sign (+), name your camera and enter its serial number *(printed inside the camera-take a photo of the SN with your cell phone for later reference)*. Click "**ADD IT**".
4. Open the camera's latches and install 12 AA batteries *(lithium or alkaline)*. Insert a new SD card *(up to 32 GB)*.
5. Move camera's power switch to the **SETUP** position, then press the **MENU** button.
6. Select your preferred method of receiving images (**Cell phone number** or **Email address**). Press **OK** on the camera's control panel.
7. Enter your cell phone number or email address *(lower case letters are not necessary or provided in email settings)*.
8. Press **MENU**. The camera will save your email address or cell number, then countdown and take a test photo. ***Note: the LCD display will power off while the camera is transmitting the image.*** *If the camera is unable to connect to a valid cell phone # or email, the display will indicate "test photo send fail".*
9. The camera displays the signal strength for the last connection. Check your cell phone or email to verify the test image was received.
10. After you have verified the camera is transmitting images, move the switch to **ON** to initiate "live" triggering, and leave the area.
11. You can now log in to your account at **wirelesstrophycam.com** to view new images, change settings, and monitor the status of one or more wireless cameras. You can also control your camera(s) remotely via the Bushnell Wireless Trophy Cam app, a free download for iPhone® and Android™.

Bushnell® TROPHY CAM HD WIRELESS

iPhone® is a registered trademark of Apple Inc.
Android™ is a trademark of Google Inc.

1


ACCOUNT LOGIN
E-mail Address
Remember Me
Forgot Password
LOGIN
SET UP A NEW ACCOUNT!
Manage your wireless trailcams
Purchase wireless data
View, edit and share photos

2


NEW ACCOUNT REGISTRATION
USER INFORMATION
LOGIN INFORMATION
NOTIFICATION SETTINGS

3

MY CAMERAS
GET STARTED
ADD A CAMERA
Give your TrailCam a name
My Trail Cam
Serial Number
BW2013
ADD IT!

BW2013090002430496
TROPHY CAM HD WIRELESS
SIMPLE 3-STEP SETUP
Install Batteries & SD card
Register Camera Online
Hang on favorite tree

4

32GB

5

Video/Up
Camera/Down
Left
Shot/Right
Replay/OK
Menu
OFF
Setup
ON
Bushnell

6


Wireless Settings
Send images to:
Cell phone number
Email address
Edit:
OK
Cancel:
MENU

7


Cell Phone Settings
Enter Phone Number:
8004233537
Save:
MENU

8


Test photo countdown
in 5 Seconds
Press MENU to CANCEL